



# B11 Pro Alarm Clock Radio Speaker System for iPhone

 Lightning Connector

 Bluetooth



homtime.com


## Safety

1 Features .....	1
2 What's Included .....	1
3 Technical Specifications .....	2
4 Buttons / Display Icons .....	3
4.1 Main Unit .....	3
4.2 Remote Control .....	4
4.3 LCD .....	5
5 Settings and Operation .....	5
5.1 Backup Battery Installation .....	5
5.2 Using the Power Adapter .....	6
5.3 Turning On/Off and Standby Mode .....	6
5.4 Setting the Time .....	6
5.5 Syncing Time with Apple Devices .....	7
5.6 Setting the Alarm Clock .....	7
5.6.1 Alarm Clock Volume .....	8
5.6.2 Snooze .....	8
5.6.3 Turning Off the Alarm Clock .....	8
5.6.4 Alarm Duration and Auto Shut-off .....	9
5.6.5 Alarm Clock Time Memory .....	9
6 Playing Music .....	9
6.1 Dock Playing Mode .....	9

6.2 USB1 Playing Mode .....	10
6.3 Bluetooth Playing Mode .....	11
6.4 AUX IN Playing Mode .....	12
7 Handsfree Calls .....	13
8 FM Radio .....	13
9 Charging Devices .....	14
10 Sleep Mode .....	14
11 LCD Brightness .....	14
12 Mute .....	15
13 Reset .....	15
14 Customized version.....	15

## Safety Information

### IMPORTANT:



Please read and follow all safety instructions before operating your Homtime B11 Pro unit.

If you have any other questions on how to operate this product and are unable to find the answer here, please contact our customer service team for assistance.

### SAFETY INSTRUCTIONS

- To ensure optimal and safe operation of the B11 Pro, please read and follow all instructions contained within this manual.
- Please keep this manual for future reference.
- To avoid electric shock, please do not remove any cover of the unit, or tamper with the casing.
- To ensure proper operation and avoid any malfunction or damage to the unit, avoid exposing it to direct sunlight, liquids, extreme temperatures, extreme humidity, excessive dust and moisture, or excessive vibrations.
- During operation, the B11 Pro may emit a low-level magnetic field; it is advised to keep hard disks, tapes, or other media that may be affected by magnetic fields away from the unit.
- Use a damp cloth to remove dust or dirt; do not use solvents to clean the the unit, and do not pour liquids on it.
- Should the B11 Pro require maintenance or servicing, do not attempt to fix it yourself; take the unit to an accredited service center for repairs or maintenance.



- To avoid damage or accidents, please use the power adapter included with the unit. Consult a service center or your retailer for a suitable replacement, when necessary.
- To avoid damage or malfunction, use accessories or attachments approved by the manufacturer.

## 1. Features

- Music playback via a Lightning or USB cable; compatible with all Apple products
- FM radio function can store up to 20 preset stations
- Built-in Bluetooth connectivity for playing music and making handsfree calls
- Dual-USB charging ports with 2A output (supports iPad)
- Can charge up to three devices simultaneously
- Easy alarm setting with snooze function
- Easily readable LCD
- IR remote control
- 3.5mm AUX IN cable
- Touch-sensitive keys

## 2. What's Included

The following items are included in your purchase:

- |                              |                    |
|------------------------------|--------------------|
| 1 x B11 Pro unit             | 1 x remote control |
| 1 x AC adapter               | 1 x user manual    |
| 1 x AUX IN cable             | 1 x warranty card  |
| 2 x 3V button-type batteries |                    |

### 3. Technology Specifications

Output power: 5W+5W

Frequency: 20-70Hz

S/N ratio: >70dB

Distortion: <1%

Power adapter: 100-240V, 50/60Hz, 12V DC, 3A

Connection via Lightning or USB cable

AUX IN: 3.5mm audio cable

Dimensions: 5.8 x 4.8 x 4.6in



Net weight: 2.05lb

## 4. Buttons / Display Icons

### 4.1 Main Unit


#### • Front View /Back View

- ① Top knob: Adjust volume/turn on or off/adjust brightness/snooze/ set alarm/reset
- ② Apple Lightning connector
- ③ USB1: Charge/connect to Apple device
- ④ USB2: Charging(2A)
- ⑤ AUX IN jack
- ⑥ Fm external antenna
- ⑦ Set time button
- ⑧ Adjust time forward
- ⑨ Adjust time backward
- ⑩ DC adapter socket









#### • Top buttons


- ⑪ Quick reverse/previous song
- ⑫ Play/pause/scan
- ⑬ Fast forward/ next song
- ⑭ Mode selection (in order):















Dock, USB1, Bluetooth, AUX, FM radio, set alarm clock


## 4.2 Remote control

- ⑮  Turn-on/off
- ⑯ “Mode”select and alarm clock button
- ⑰ “TUN +”: In FM radio mode, press quickly to scan forward on FM bandwidth; press and hold to auto-search next station
- ⑱ Scan and store stations on FM radio mode
- ⑲ “TUN -”: In FM radio mode, press quickly to scan backwards on FM bandwidth; press and hold to auto-search next station
- ⑳  Adjust LCD brightness
- ㉑  Set alarm clock
- ㉒ “SNOOZE”
- ㉓ “SLEEP”
- ㉔ “MUTE”
- ㉕  Press and hold to fast forward/press quickly for next song Play/Pause
- ㉖  Play/pause song
- ㉗  Press and hold to rewind/press quickly for previous song
- ㉘ “+”: Increase volume/set or adjust time
- ㉙ “TIME”: Time set mode/adjust time
- ㉚ “-”: Decrease volume/set or adjust time
- ㉛ “RESET” – Reset to previous settings




## 4.3 LCD

- ③② Hour display
- ③③ Minutes display
- ③④  USB1 audio input playing mode
- ③⑤  Lightning Connector audio input playing mode
- ③⑥  Bluetooth playing mode
- ③⑦  AUX IN playing mode
- ③⑧  188.8 ST MHz FM radio mode/FM frequency display
- ③⑨  12H display mode: AM/PM
- ④①  Snooze mode
- ④②  Alarm clock active
- ④③  Alarm clock time setting mode
- ④④  Sleep mode
- ④⑤  USB1 charging icon
- ④⑥  USB2 charging icon




## 5 Settings and operation

### 5.1 Backup battery installation



## 5.2 Using the power adapter



## 5.3 Turning on/off and standby mode

After connecting the adapter to a 100-240V electrical outlet and turning on the power, the B11 Pro unit will go into standby mode. The time and alarm clock will be displayed on the LCD. Press the top knob to turn the unit on. Press and hold the top knob to turn the unit off; the unit will display the time and enter standby mode.

## 5.4 Setting the Time

- Setting the time using the unit's buttons

Press ⑦ once to set the time. Press ⑦ again to adjust; you will see the hour display flash. Press “+” or “-” to adjust the hour, and press ⑦ again to confirm. The minutes display will then flash, and use “+” or “-” to adjust the minutes, then press ⑦ to confirm the setting. You can change the time mode from 12 to 24 hours by pressing ⑧. The time set will be automatically stored after 10 seconds.

- Setting the time using the remote control

Press the “TIME” button on the remote control. Press the “TIME” button again and the hour display will flash; adjust the hour with “+” or “-” and then press “TIME” to confirm. The minutes display will flash next; use “+” or “-” to adjust, then press “TIME” to confirm. The time set will be automatically stored after 10 seconds.

## 5.5 Syncing time with Apple devices

Turn on the unit and connect your Apple device with the Lightning connector. The unit will automatically sync its time setting with your Apple device. You will hear a sound and see **sync** on the LCD, which indicates that the devices are synced.

## 5.6 Setting the alarm clock

- Setting the alarm clock via the unit's buttons



Inner ringtone



Dock ringtone



USB1 ringtone



Radio ringtone



Clock turn-off

Turn on the unit, press the knob key to enter into the alarm settings mode; rotating the large knob to select “on” or “off”, pressing to confirm.



- Setting alarm tone by revoting control key to switch among “built-in tone”, “dock music tone”, “USB1 audio tone”, “FM radio audio tone”, pressing to confirm, setting alarm clock volume by rotating the key, pressing to confirm. setting the alarm time by rotating the control key, pressing to confirm. Pressing the control key to finish alarm clock seething, and the unit will change into dock playing mode.

#### 5.6.1 Alarm clock volume


Please note that the alarm clock tone will start out soft, and will gradually get louder until the volume reaches the level to which it is set.

#### 5.6.2 Snooze

When the alarm clock rings, quickly press the large knob, or press the “SNOOZE” button to put the unit on snooze. A “snooze” icon will appear on the LCD, and the alarm will reactivate after 9 minutes.

#### 5.6.3 Turning off the alarm clock

- Turn off the alarm quickly

Press and hold the knob until the  disappears on the LCD. The alarm set will only work for the next 24-hour period. To remove the last set alarm, press the large knob when in alarm clock setting mode.

#### 5.6.4 Alarm duration and auto shut-off

If no buttons are pressed, the alarm will automatically shut off after 30







minutes.


### 5.6.5 Alarm clock time memory

If no alarm settings are changed, the unit will keep and use the last alarm clock setting.






## 6. Playing music


### 6.1 Dock playing mode

- By default, the unit will start at dock playing mode. This mode can also be set using the remote control. Simply connect your iPhone to the Lightning USB port to play music.
- Press  to play or pause. Quickly press  to play the previous song, press and hold  to quickly scan the current song in reverse. Press  quickly to go to the next song, and press and hold  to fast-forward the song. Adjust the music volume by rotating the large knob .
- The same buttons and functions are also found on the remote control. Use the “+” and “-” to adjust the music volume.




## 6.2 USB1 playing mode

- Turn on the unit, press the “MODE” button on the remote control and choose USB playing mode.
- An icon will appear on the LCD after connecting your device with the USB cable. Press  to play or pause. Quickly press  to play the previous song, press and hold  to quickly scan the current song in reverse. Press  quickly to go to the next song, and press and hold  to fast-forward the song. Adjust the music volume by rotating the large knob ① .









### 6.3 Bluetooth playing mode


- Bluetooth activation and syncing


Turn on the unit, press  or press “MODE” on the remote control to choose Bluetooth mode. The Bluetooth icon will flash, indicating that it is ready to sync with a Bluetooth-enabled device. Turn on the Bluetooth feature on your iPhone/iPad/iPod, and pair with “B11” (no password needed). The unit and your device will sync after you hear a tone, and the Bluetooth icon will be shown constantly on the LCD.

- Playback and controls



In Bluetooth mode, press  to play or pause. Quickly press  to play the previous song, press and hold  to quickly scan the current song in  reverse. Press  quickly to go to the next song, and press and hold  to fast-forward the song. Adjust the music volume by rotating the large knob ①. The same buttons and functions are also found on the remote control. Use the “+” and “-” to adjust the music volume.


- Bluetooth disconnection and turning off

Press  on the unit or the “MODE” button on the remote control to switch to another mode, and turn the Bluetooth mode off. Please note that the B11 Pro can sync with only one Bluetooth device at a time. To switch to another device, turn off and disconnect the current device, and sync the B11 Pro with the other device.



#### 6.4 AUX IN playing mode



Turn on the unit, press  button, or “MODE” on the remote control, to choose the AUX IN playing mode. The  icon will appear on the LCD. Connect the 3.5mm audio cable to the AUX IN jack, and to your iPhone/iPad/iPod.




## 7. Handsfree calls

To make handsfree calls, simply sync your iPhone with the unit via Bluetooth. The handsfree function will automatically start when you receive a phone call. Quickly press the large knob ① to answer a call, and quickly press it again to hang up.

## 8. FM radio

- To use the FM radio, turn on the unit, then switch to FM radio mode. Press and hold “SCAN” to auto-scan radio stations; release the button then press and hold again to save the current FM station. Up to 20 radio stations can be saved, and the FM frequency ranges from 87.5MHz to 108MHz. Press  once or  to select stations.
- If station reception is poor, please extend the FM radio antenna.

## 9. Charging devices

- You can charge your iPhone or other smart device as long as it is compatible with the USB ports in the unit.
- The unit can charge up to 3 iPhones or different Apple devices by using ②、③ and ④ .
- The charging status of ③ and ④ will be shown on the LCD. Once charging is completed, the  will disappear.
- Jack ④ or USB2 is for fast charging with 2A output.

## 10. Sleep

When the unit is on, press “SLEEP” on the remote control to make the unit automatically shut off after a desired time. You can set the unit to SLEEP after as little as 10 minutes or as much as 90 minutes have passed. When set, the unit will keep the setting after 5 seconds and then return to its previous status. To see how much time is left before the unit goes on sleep mode, press the before the unit goes on sleep mode, press the “SLEEP” button.

## 11. LCD brightness

- Quickly press the large knob ① to adjust LCD brightness; choose from three different levels.
- On the remote control, press ②⑨ to adjust LCD brightness. This can be done whether the unit is on or off.

## 12 MUTE

Press “MUTE” on the remote control to temporarily turn off the sound.

## 13 RESET

- Press “RESET” on the remote control; this will reset the current mode to dock playing mode, and clear the alarm clock setting. This will turn off the alarm clock.
- You can also press the large knob ① on the unit for more than 8 seconds to “RESET” the unit to dock playing mode, clear the alarm clock setting, and turn off the alarm clock.

## 14 Customized version

- Alarm settings



Radio ringtone



Clock turn-off

Turn on the unit, press the “MODE” button and enter the alarm setting. The alarm clock display icons will start to flash on the LCD. When in this mode, rotate the large knob on the unit, select alarm “on” or “off” by pressing the large knob to confirm. Select “on” and then set the alarm time by turning the knob to the desired time, pressing to confirm. To turn off the alarm clock, press ① and the unit will switch to dock playing mode. (\*Feature available in customized version only)





Shanghai Funner Electronic Technology Co.,Ltd.

[www.homtime.com](http://www.homtime.com)